


COLUMBIA BOAT ALARMS, INC.

PROGRAM KEY-FOB REMOTES TO Model 411 CONTROL PANEL

1. Apply power to control panel and open the control box.
2. Notice the slide switch, make sure it is moved toward the small circuit board.
3. Tucked in under the nut for the cable gland there is a small program button on the small circuit board.

The program button



TO REMOVE ALL KEY-FOBS FROM MEMORY

This step erases all key-fobs from memory.

Note that a key-fob may be added without erasing the memory.

Depress and hold the small program button down until red LED on the small circuit board flashes.

TO PROGRAM A NEW KEYFOB INTO MEMORY

- Press the small program button momentarily.
- Hold the new key-fob close to the small circuit board and press the LOCK button.
- The small red LED will flash.
- Press the small program button to lock the key-fob into memory.
- To program additional key-fobs repeat the above procedure.
- After adding the key-fob wait about 10 seconds or press the unlock button.
- Test the key-fob operation.

Note that a key-fob may be added without erasing the memory.